
RK95 Charging & Comm. Cradle Quick Start Guide

Basics


Open Your Box

- ☑ RK95 Charging & Communication Cradle (***CCCR*** Model or ***ENCR*** Model)
- ☑ AC Adapter
- ☑ AC Plug (optional)
- ☑ Micro USB Cable (optional; only for ***CCCR*** Model)
- ☑ Battery (optional)
- ☑ Quick Start Guide




The RK95 Charging & Communication Cradle allows charging and data transmission of the RK95 Mobile Computer. Aside from a main charging station, the cradle is equipped with a spare battery compartment to help maintain a charged spare battery for your convenient use.

Overview



The RK95 Charging & Communication Cradle offers 2 models: one is with a Micro USB port which supports USB OTG communication (CCCR Model) while another is with a RJ45 Connector for Ethernet communication (ENCR Model).




Installation

Main Charging Station:
Insert the RK95 mobile computer onto the Cradle.

The installed rubber boot is not necessary to be removed in advance before inserting the mobile computer.


To remove, please take out the RK95 mobile computer directly.




Spare Battery Compartment:

Step 1:
Insert the battery from its top side into the spare battery comparment.

Step 2:
Press down the bottom side of the battery.
A "click" sound is made once the battery is in place.




To remove the battery from the spare battery comparment, please place your finger into the groove and pull to take the battery out.



LED Indicators

LED on RK95 mobile computer:
Indicates the charging status of the main battery.

LED on Cradle:
Indicates the charging status of the spare battery.




LED Indicator on RK95 Mobile Computer (for main battery)

Status	Description
Red, solid	Charging the main battery in the RK95 mobile computer.
Red, blink	Charging error
Green, solid	Charging complete
No light	Not charging. It might result from the power cable which is not correctly connected.


LED Indicator on Cradle (for spare battery)

Status	Description
Red, solid	Charging the spare battery
Red, blink	Charging error
Red, flash once	No battery is in the spare battery compartment. (when the adapter is plugged in)
Green, solid	Charging complete

Charging & Communication



Note:
The Cradle is equipped with either one Micro USB Connector (CCCR model) or one RJ45 Connector (ENCR model).



Important Charging Information	
Power Supply	Input: AC 100 - 240V, 47 - 63Hz Output: 4.75V - 5.4V, 2A (Maximum) CipherLab approved
Battery Pack (optional)	3.7V, 3000mAh rechargeable Li-ion battery, 3.7V, 6000mAh rechargeable Li-ion battery, CipherLab proprietary
Charging Time	Approx. 4 hours (3000mAh); 6 hours (6000mAh)


RK95 行動電腦傳輸充電座 快速開始指南 >

繁中 简中

基本操作／基本操作

檢視包裝內容物／检视包装内容物


- ☑ RK95 傳輸充電座／RK95 传输充电座 (***CCCR*** 機型 或 ***ENCR*** 機型 ／***CCCR*** 机型 或 ***ENCR*** 机型)
- ☑ 電源轉換器／电源转换器
- ☑ 電源線 (選配) ／电源线 (选配)
- ☑ Micro USB 傳輸線／Micro USB 传输线 (選配；僅供 ***CCCR*** 機型 ／选配；仅供 ***CCCR*** 机型)
- ☑ 電池(選配)／电池(选配)
- ☑ 快速開始指南／快速开始指南




RK95 傳輸充電座可用於RK95 行動電腦的資料傳輸與充電。本裝置除主機傳輸充電槽外，另設有備用電池充電槽，方便隨時備有電量充足的備用電池。

RK95 传输充电座可用于RK95 行动电脑的资料传输与充电。本装置除主机传输充电槽外，另设有备用电池充电槽，方便随时备有电量充足的备用电池。

概覽／概览



RK95 傳輸充電座分為二機種：一為CCCR 機型，設有Micro USB埠，可支援USB OTG傳輸；另一則為ENCR 機型，透過RJ45連接線可連線至乙太網路。
RK95 传输充电座分为二机种：一为CCCR 机型，设有Micro USB埠，可支援USB OTG传输；另一则为ENCR 机型，透过RJ45连接线可连线至乙太网络。




安裝／安装

主機傳輸充電槽：
請將RK95 行動電腦主機置入充電槽中。
機身若裝有保護殼，無需卸除即可
直接置入充電槽。

如需移除，請直接取出主機即可。

主机传输充电槽：
请将RK95 行动电脑主机置入充电槽中。
机身若装有保护壳，无需卸除即可
直接置入充电槽。

如需移除，请直接取出主机即可。



RK95 行动电脑传输充电座 快速开始指南 >>


繁中 简中


備用電池充電槽：
步驟1：由電池頂端將電池放入備用電池充電槽中。
步驟2：將電池底端下壓入備用電池充電槽內至『喀』聲響。

取出備用電池充電槽中的電池，請將手指伸入凹槽中，再將電池向上帶出即可。

备用电池充电槽：
步骤1：由电池顶端将电池放入备用电池充电槽中。
步骤2：将电池底端下压入备用电池充电槽内至『喀』声响。

取出备用电池充电槽中的电池，请将手指伸入凹槽中，再将电池向上带出即可。






LED充電指示燈／LED充电指示灯

RK95 行動電腦主機上的LED指示燈：
顯示裝置在主機內的主電池充電狀況。

傳輸充電座上的LED指示燈：
顯示置於備用電池充電槽內的備用電池充電狀況。


传输充电座上的LED指示灯：
显示置于备用电池充电槽内的备用电池充电状况。




RK95 主機上的LED指示燈(主電池)／RK95 主机上的LED指示灯(主电池)	
狀態／状态	**說明／说明**
紅燈恆亮 红灯恒亮	裝置於RK95 行動電腦內的主電池充電中 装置于RK95 行动电脑内的主电池充电中
紅燈閃爍 红灯闪烁	充電錯誤，充電將會停止 充电错误，充电将会停止
綠色恆亮 绿色恒亮	充電完成 充电完成
沒有燈亮 没有灯亮	無法充電 (充電線端未正確連接本機或插座) 无法充电 (充电线端未正确连接本机或插座)

傳輸充電座上的LED指示燈 (備用電池) 传输充电座上的LED指示灯 (备用电池)	
狀態／状态	**說明／说明**
紅燈恆亮 红灯恒亮	備用電池充電中／备用电池充电中
紅燈閃爍 红灯闪烁	充電錯誤／充电错误
紅燈閃爍一次 红灯闪烁一次	電池未置入備用電池充電槽 (當電源接上時) 电池未置入备用电池充电槽 (当电源接上时)
綠燈恆亮 绿灯恒亮	充電完成／充电完成

充電及資料傳輸／充电及资料传输



注意：傳輸充電座只會配備一Micro USB埠 (CCCR 機型)或一RJ45 插孔(ENCR 機型)
注意：传输充电座只会配备一Micro USB埠 (CCCR 机型)或一RJ45 插孔(ENCR 机型)



重要電源資訊／重要电源信息	
電源轉換器 电源适配器	**輸入／输入：AC 100 - 240V, 47 - 63Hz 輸出／输出：4.75V - 5.4V, 2A CipherLab專用電源供應器／CipherLab专用电源适配器**
電池容量（可選） 电池容量（可选）	**3.7V, 3000mAh／3.7V, 6000mAh CipherLab 專用充電式鋰電池 CipherLab 专用充电式锂电池**
充電時間／充电时间	**3.7V, 3000mAh：約4小時／约4小时 3.7V, 6000mAh：約6小時／约6小时**

P/N: SRK95AQG01004

Copyright©2019 CipherLab Co., Ltd.

RK95 行动电脑传输充电座 快速开始指南 >>>

繁中 简中