

**Compatible with:**

Samsung Xcover Pro SM-G715
OtterBox uniVERSE Case

View Color Instructions**Important:**

Self-installation instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical ability required to properly perform an installation. ProClip USA, LLC. shall have no liability for damage or injury resulting from the installation or use of any ProClip or third party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to allow it to be operated safely and without distraction. ProClip USA, LLC. product warranties do not cover the installation, removal or re-installation of any product.

Warning:

This product is not certified for drop rating. Dropping the RFD40 with a phone docked and this plate attached may result in damage that is not covered under warranty.

Attention:

Carefully read all instructions and review the images before installing this product.

**1. Loosen RFD40 Top Cover:**

To install this adapter, remove the top cover plate on the RFD40 RFID Reader.

Start by gently prying the top of the plate away as shown above.

**2. Remove Top Cover:**

Once loose, the top cover can be removed completely and set aside for any future needs.

**3. Align the Adapter Plate:**

This adapter plate is designed to fit into the RFD40 exactly to seal the product and securely fasten to it. Align the 4 screw holes with the top of the RFD40.

**4. Press Plate Into Place:**

When aligned, gently press the plate into place. The O-ring will provide a small amount of resistance as it settles into position.



5. Attached Plate with Fasteners:
Using the 4 included fasteners, secure the plate to the RFD40 with a Philips #1 screwdriver. Note that the fasteners should only be tightened to finger tight. (.7 Nm or .51 Ft-lb of force).



6. Otterbox uniVERSE Rail:
This product is designed to work with the Otterbox uniVERSE case system and utilizes rail attachment point next to the USB-C connector on the Samsung Xcover Pro. Remove the rail cover from the uniVERSE case before attaching to the rail.



7. Slide onto Rail:
Using the grooved sides of the case, slide the phone down over the top of the rail to align the case and the phone. NOTE: This only fits the Samsung Xcover Pro phone.



8. USB-C Connection:
The phone will slide down and click into position when the USB-C connector is docked. This will enable the Samsung Xcover Pro to control the Zebra RFD40 with the 123RFID Mobile application loaded onto the device.

Returns

All returns must be made within thirty (30) days of the delivery date and include proof of purchase, a copy of your original order, or invoice. No products shipped hereunder may be returned without ProClip USA's prior approval. In order to return a product, the buyer must obtain an RMA number (Return Merchandise Authorization Number). **Items returned without a valid RMA number may be rejected. Items that are open, used, damaged, or returned without all original components may have a restocking fee applied.**

Limited Warranty and Liabilities

ProClip warrants that the Products will be free of defects in materials and workmanship for a period of one (1) year from the date of purchase. If any Product should become defective within the warranty period, ProClip, at its option, will replace it, repair it or refund the purchase price. Repair or replacement parts or Products will be furnished on an exchange basis and will either be new or reconditioned. All replaced Products shall become the property of ProClip. Warranty service is available to you by delivering the Product during the warranty period to the company it was purchased from or to ProClip at 4915 Voges Rd., Madison, WI 53718 USA and providing proof of purchase, price and date. If shipped to ProClip, the buyer must first call ProClip at +1 800-296-3212 or e-mail ProClip at returns@proclipusa.com to obtain a return approval and return number. You will bear all shipping, packaging and insurance costs and all other costs, excluding labor and parts, necessary to effectuate repair, replacement or refund under this warranty. For more information on how to obtain warranty service, write, e-mail or telephone ProClip at 4915 Voges Rd., Madison, WI 53718 USA. Tel: +1 800-296-3212, e-mail: returns@proclipusa.com.

THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCT WHICH HAS BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE OR AS A RESULT OF UNAUTHORIZED SERVICE. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES FOR THIS PRODUCT. IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT SHALL HAVE NO GREATER DURATION THAN 1 YEAR FROM THE DATE OF PURCHASE. IN THE EVENT THIS PRODUCT BECOMES DEFECTIVE DURING THE WARRANTY PERIOD, THE PURCHASER'S EXCLUSIVE REMEDY SHALL BE REPAIR, REPLACEMENT OR REFUND AS PROVIDED ABOVE. IN NO EVENT SHALL PROCLIP BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION LOSS OF PROPERTY, ARISING FROM BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY. PROCLIP DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE SET FORTH ABOVE. IN NO EVENT WILL PROCLIP BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, INDIRECT, SPECIAL, PUNITIVE, OR EXEMPLARY DAMAGES, INCLUDING ATTORNEY FEES ARISING OUT OF THE USE OF OR THE INABILITY TO USE THE PRODUCTS, OR FOR ANY CLAIM BY ANY OTHER PARTY, EVEN IF PROCLIP HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Regulatory information: www.proclipusa.com/regulatory.html

ProClip USA, LLC • 4915 Voges Road • Madison, WI 53718 • USA

Office: +1 608-807-5320 • Fax: +1 920-372-0066 • Toll free: 800-296-3212 • Internet: www.proclipusa.com